



VEBO Metal Tube Dog Cage with Wheels

Assembly Instructions



Item List



Cage main body x 1



PP Plastic tray x 1



Top panel x 1



Heavy Duty wheel x 4



Wind bolt screw x 2



Top panel screw x 2



Normal screws x 9

Instruction

No.1



Open package and take cage out

No.2



Turn cage upside down and install the heavy duty wheels as illustrated.

Instruction

No.3



Pull the rear panel up

No.4



Pull the front panel up

No.5



Pull left side panel up then install 2 normal screws clockwise at high lighted position.

No.6



Pull right side panel up then install another 2 normal screws clockwise at high lighted position.

No.7



Install top panel. Use the top panel screws (bigger, flat head) at high lighted position.

No.8



Install the wind bolt screws at high lighted position.